



The stepper motor can also be connected to an external power source. I use a PC power supply for this. You can use a red (5V) and a black wire from the power supply to power the driver board. To turn on a PC power supply you have to connect the green wire to one of the black wires.